



## BATTERY OPTIONS

| Type  | Dimensions             | Nominal Voltage | Usability  |
|---|------------------------|-----------------|--|
| 18650 Rechargeable (Li-ion) [6.0 / 8.0 / 10.0]        | 18650                  | 3.7V            | Yes<br>(recommended for optimal performance)       |
| Non-rechargeable Battery (Alkaline)                   | AAA<br>AA (4.0XL only) | 1.5V            | Yes<br>(expect lower runtimes & light performance) |
| Non-rechargeable Battery (Lithium) [6.0 / 8.0 / 10.0] | CR123A                 | 3V              | Caution**<br>(not recommended)                     |

### Warning

1. Please do not mix old and new batteries and do not mix batteries of different brands, size, capacity or type (standard alkaline (carbon-zinc) or rechargeable (ni-cad, ni-mh, etc.) Doing so may cause damage to the flashlight or the batteries being used.

2. Do not use the supplied 18650 charger to charge other battery types or may cause explosion.

\* 18650 Li-ion batteries are powerful cells designed for commercial applications and must be treated with caution and handled with care. Quality batteries with circuit protection will reduce the potential risk for combustion or explosion but cell damage or short circuiting are potential risks the user assumes.

\*\* The B.A.M.F.F. can be powered using two CR123A lithium batteries for emergency situations, but the circuitry is not designed for the additional voltage. Usage of this battery will result in a shortened lifespan and void the warranty.

### BAMFF 10.0 Gun Mount

1. Remove the belt clip from the BAMFF 10.0 by removing the two hex screws.
2. Remove the two hex drive screws from the gun mount and separate the gun mount body.
3. Install the BAMFF 10.0 into the gun mount and reinstall the screws until tight.
4. Loosen the thumb screw on the rail mount and carefully slide the gun mount onto your gun picatinny rail.
5. Tighten the thumb screw.
6. Mount the remote pressure switch on the gun where it is comfortable to use and control. Secure with zip-ties, dual sided tape, or Velcro. To avoid burns or melting, ensure the pressure switch and wire do not contact the barrel.

### USAGE AND MAINTENANCE

Please do not disassemble the sealed head, doing so can cause damage to the flashlight and will void the warranty.

We recommend the use of high quality batteries. If the flashlight is not to be used for an extended period of time, remove the battery, or the flashlight could be damaged by electrolyte leakage or battery explosion.

The O-ring may be worn out after using the flashlight for a long time. If this happens, please replace the O-ring with a new one to keep the flashlight properly sealed against water.

Please clean the contacts of your flashlight from time to time, especially if the light flickers or doesn't light up. There may be several reasons for a flickering or not working light.

Reason A: The battery needs replacing.

Solution: Replace the battery (please confirm the correct orientation of the positive and negative ends)

Reason B: The threads, PC Board contact or other contacts are dirty.

Solution: Clean the contact points with an alcohol soaked cotton swab.

If the above methods don't work. Please refer to the warranty policy.

### PRODUCT WARRANTY

We will repair or replace products with manufacturing defects within 1 year of purchase with normal use, proof of purchase required. Please visit [STKRconcepts.com](http://STKRconcepts.com) for warranty policy and contact information.

### WARNING

The B.A.M.F.F. is a high intensity lighting device capable of causing eye damage. Avoid shining the light directly into anyone's eyes.



**QUESTIONS?** Before returning to your retailer, call our customer service department at 704-508-1031, 8 a.m. - 5 p.m. EST, Monday - Friday or email us at [info@STKRconcepts.com](mailto:info@STKRconcepts.com)



BATTERIES MUST BE RECYCLED OR DISPOSED OF PROPERLY

